


Hydro-Jet Drain Cleaner

Supplied by Centenary Hire. Ph: (07) 3715 9700

INSTRUCTIONS FOR USE: Please read carefully before putting machine into operation!

GENERAL SAFETY PRECAUTIONS



Personal protective equipment (PPE) must be worn at all times

Wear appropriate safety footwear & gloves with a strong upper material which will protect against accidental passage of high pressure water over the operator's feet or hands.

Place warning signage in position appropriate to the need, including barricading the work area from public as required.



DO NOT spray or aim the jet nozzle directly at or in the direction of a



person, animal or electrical equipment as SERIOUS INJURY or DEATH may result. SEEK MEDICAL ADVICE IF SKIN IS BROKEN.



Jet nozzle must be de-activated when at a length of less than 1 meter inside the pipe. Use red indicator bands as a guide.

OPERATING INSTRUCTIONS

PRE WORK CHECKS:

Check high pressure hose/s for damage ie: splits, cracks.

Check the entry point to the drain to ensure there are no obstructions that may cause damage to the high pressure hose as it travels in and out of the pipe.

HYDRO-JETTING INSTRUCTIONS:

1. Connect the Hydro-Jet Assembly to the water pressure cleaner using the high pressure hose.
2. Ensure that the Hydro-Jet Assembly valve handle is in the 'OFF' position.
3. Release the reel lock & insert the jet nozzle into the pipe to be cleared & push it in a minimum of 1m. Use red indicator bands as a guide.
4. Start the water pressure cleaner motor according to the instructions provided with that equipment & run at full throttle.



NEVER START OR RUN THE WATER PRESSURE CLEANER WITHOUT A WATER SUPPLY.

5. Turn the Hydro-Jet Assembly valve handle to the 'ON' position.
6. With minimal assistance the jet nozzle will pull the high pressure hose into the pipe in the direction that it was inserted until a blockage is reached.
7. Continue jetting the blockage with small pull & release movements of the high pressure hose until you are satisfied that the blockage is clear.
8. Once the blockage is clear, turn the Hydro-Jet Assembly valve handle to the 'OFF' position, leaving the high pressure hose in the pipe.
9. Turn off the high pressure water cleaner motor in accordance with the instructions provided with that equipment.
10. Turn to the Hydro-Jet Assembly valve handle to the 'ON' position to relieve the pressure in the high pressure hose.
11. Disconnect the Hydro-Jet Assembly from the water pressure cleaner.
12. Retract the jet nozzle by winding the high pressure hose onto the reel & engage reel lock when complete.

DURING USE



DO NOT lock/secure the Hydro-Jet Assembly valve handle in the 'ON' position.



DO NOT spray or aim the jet nozzle directly at or in the direction of a person, animal or electrical equipment as SERIOUS INJURY or DEATH may result.



DO NOT remove the jet nozzle from the pipe while it is activated.



DO NOT leave machine running while unattended.